



ASSEMBLY INSTRUCTIONS

- Loosen the fixing screws of the fixing plate and remove it (a) from the base of the light fixture, while taking care not to loose the gaskets. (photo 1 and 2).

INSTALLATION ON FRAGILE SURFACES

- Use the accessory for ground buried installation.
- Before you bury or concrete the recessed installation accessory, prepare a 20 cm layer of draining gravel underneath (fig. 4).
- Introduce the tube for the passage of the supply cables into the holes in the recessed installation accessory (fig. 5).
- Fix the recessed installation accessory, taking care that the upper part is in line with the installation surface (fig. 4).
- Fix plate (a) on the counter-plate which is fixed on the upper end of the recessed accessory by means of the perimeter fixing holes (fig. 5).
- Introduce the supply cable (type H07SS-F 3 x 1,5 sq mm with diameter between 8 and 10 mm) into the cable clamp and wire the terminal, then block the cable clamp (fig. 6 and photo 3).
- Position the base of the light fixture on the plate (a) and fix it with the screws in the equipment, taking care that the slots in the base are in line with the holes of the recessed installation accessory (photo 4 and fig. 5).
- Place the lamp in the lampholder, reinstall the canopy and close it with the grub screws (photo 2 and 5).

INSTALLATION ON CONCRETE SURFACES

- Introduce the supply cable (type H07SS - F 3 x 1,5 sq mm with diameter between 8 and 10 mm) into the cable clamp and wire the terminal, then block the cable clamp (fig. 6 and photo 3).
- Use the holes on the fixing plate (a) to fix, through screw anchors (not in the equipment), this plate on the surface where the light fixture will be installed (photo 4 and fig. 5).
- Place the lamp in the lampholder, reinstall the canopy and close it with the grub screws (photo 2 and 5).