




L2033-100




L2033-150

D8-1403 LED 17W 110-120V



D8-1404 LED 25.5W 110-120V



OPERATION AND USE INSTRUCTIONS

ATTENTION: KEEP THESE INSTRUCTIONS

The safety of this fitting is only guaranteed with the use of the instruction.

Disconnect before any action on fitting.

Panzeri Carlo Srl is not responsible for any damage to persons and/or property resulting from improper installation, misuse, or unauthorized modifications made to their products.

- Fix the plate (1) and the steel cable supports (2) to the ceiling.

-Adjust the length of the steel cables by sliding them through the cable clamp. To

unlock the clamp, simply press the cylinder (3).

It is possible to change the spacing of the steel cables by sliding the two plates (4)

MAINTENANCE

Only clean the product using a soft cloth. To remove persistent marks use only a damp cloth and neutral soap

Fixtures with led: the led cannot be partially replaced. If damaged all the power supply must be replaced.



Approved by North American Standards.



The device may not be disposed of with household rubbish. This appliances is labelled in accordance with European Directive 2002/96/EG concerning used electrical and electronic appliances (waste electrical and electronic equipment – WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU. To return your used device, please use the return and collection systems available to you.