












<p>1</p>  <p>INVADER ADJUSTABLE D= 104mm(4 1/8") INVADER SMALL ADJUSTABLE D= 57mm(2 1/4")</p>	<p>2</p> <p>CDM-Rm:</p> 	<p>CR-CBC:GU5,3</p>  <p>12V</p>	<p>LED:</p>  <p>INVADER ADJUSTABLE 2700K 3000K 4000K</p> <p>500 mA</p> <p>INVADER ADJUSTABLE SMALL 2700K 3000K 4000K</p> <p>250 mA</p>
<p>120V 50Hz</p> 	<p>120V 50Hz</p>  <p>12V</p>	<p>120V 50Hz</p>  <p>500 mA</p>	
<p>3</p> <p>CDM-RM: CR-CBC: LED:</p>  <p>Open the enclosure and make the connection!</p>	<p>4</p> <p>CDM-RM: CR-CBC: QPAR-16:</p> 		
<p>5</p> <p>CDM-RM: CR-CBC: QPAR-16: LED:</p> 	<p>6</p> <p>CDM-RM: CR-CBC:</p> <p>PAR16: LED:</p>  <p>OFF</p> <p>ON</p> <p>!</p>		

Attention! Do not plug/unplug, while current is switched on!