




IP 65





IP 65



APPLY MINI

ISTRUZIONI DI MONTAGGIO - ASSEMBLY INSTRUCTIONS INSTRUCTIONS DE MONTAGE

IP 65 Stagno alla polvere e i getti d'acqua
Protected against dust and splashing
Protégé contre la poussière et les jets d'eau

Apparecchio di classe II
Class II light fixture
Appareil de classe II

Apparecchio idoneo al montaggio su superfici normalmente infiammabili
Light fixture which can be mounted on normally inflammable surfaces
Approprié pour montage sur surfaces normalement inflammables

L10W0076SP-30K-GRY

Connector IP68



Code: L10A0003

AVVERTENZE GENERALI

La sicurezza dell'apparecchio è garantita solo con l'uso appropriato delle seguenti istruzioni, pertanto è necessario conservarle.
N.B. Prima di procedere alla connessione dell'apparecchio in rete assicurarsi che sia sotto tensione.

GENERAL INSTRUCTIONS

The fitting's safety is guaranteed only with appropriate use of the following instructions, so it's necessary to keep them.
Before proceeding with the connections of the fitting be sure that there's no voltage.

INSTRUCTIONS GÉNÉRALES

La sécurité des appareils n'est garantie que si les instructions suivantes sont scrupuleusement suivies. Il est donc nécessaire de les appliquer.
Avant de procéder à la connections s'assurer que le système soit hors circuit.




FIG. 1a




FIG. 1b




FIG.2




FIG.3




FIG.4

I

Apply mini parete

- Togliere la calotta A dalla piastra B allentando (senza toglierli) i 4 grani E. FIG.1a
- Collegare il cavo dell'apparecchio al cavo di rete al di fuori dalla piastra B. FIG.2
- Fissare la piastra B a parete con viti, se necessario, tasselli adeguati (non in dotazione). FIG.2
- Rifissare la calotta A alla piastra B stringendo i 4 grani con forza per garantire l'IP. FIG.1a

Apply mini a palo

- Togliere la calotta A dalla piastra B allentando (senza toglierli) i 4 grani E. FIG.1a
- Introdurre il cavo dell'apparecchio nel palo C e collegarlo al cavo di rete. FIG.3
- Fissare la piastra B al palo usando le rondelle in gomma e acciaio e le viti a brugola in dotazione. FIG.3
- Rifissare la calotta A alla piastra B stringendo i 4 grani con forza per garantire l'IP. FIG.1a/1b

Fissaggio palo con base

- Fissare la piastra D del palo a pavimento con viti e tasselli adeguati. FIG.3

Fissaggio palo da interrare

- Prima di interrare e/o cementare il palo creare nella zona di alloggiamento, uno strato di ghiaia sufficiente a garantire l'eventuale deflusso dell'acqua (circa 30cm) FIG.4
- Introdurre nell'apposita cava del palo il tubo corrugato T (FIG.4)

GB

Mini Apply wall

- Remove the cover A from the plate B by loosening (without remove them) the 4 grains E. FIG.1a
- Connect the cable of the fitting to the network cable externally to the plate B. FIG.2
- Fix the plate B to the wall with screws and, if necessary, suitable dowels (not supplied). FIG.2
- Fix again the cover A to the plate B by tightening strongly the 4 grains to ensure the IP. FIG.1a

Apply mini pole

- Remove the cover A from the plate B by loosening (without remove them) the 4 grains E. FIG.1a
- Insert the cable of the fitting into the pole C and connect it to the network cable. FIG.3
- Fix the plate B to the pole using the supplied rubber and steel washers and the Allen screws. FIG.3
- Fix again the cover A to the plate B by tightening strongly the 4 grains to ensure the IP. FIG.1a/1b
- Fixing the pole with base
- Fix the plate D of the pole to the floor with suitable screws and dowels. FIG.3
- Fixing the pole for buried installation
- Before burying and/or cementing the pole, pay attention to create a layer of gravel for drainage, enough to guarantee the possible water flow (about 30cm) FIG.4
- Insert the corrugated tube T into the appropriate pit of the pole. FIG. 4

F

Apply mini version au mur

- Enlever le couvercle A de la plaque B en dévissant (sans les enlever) les 4 vis E. FIG.1a
- Brancher le câble de l'appareil avec le câble de réseau à l'extérieur de la plaque B. FIG.2
- Fixer la plaque B au mur avec des vis et, si nécessaire, des chevilles appropriées (non fournies). FIG.2
- Remettre le couvercle A sur la plaque B en serrant les 4 vis avec force pour assurer l'IP. FIG.1a

Apply mini version pôle

- Enlever le couvercle A de la plaque B en dévissant (sans les enlever) les 4 vis E. FIG.1a
- Introduire le câble de l'appareil dans le pôle C et le brancher au câble du réseau. FIG.3
- Fixer la plaque B au pôle en utilisant les rondelles en caoutchouc et acier et les vis 6 pans fournies. FIG.3
- Remettre le couvercle A sur la plaque B en serrant les 4 vis avec force pour assurer l'IP. FIG.1a/1b

Fixation du pôle avec la base

- Fixer la plaque D du pôle au sol avec des vis et chevilles appropriées. FIG.3

Fixation du pôle à enterrer

- Avant d'enterrer et/ou ciment le pôle, faire attention à créer dans la zone de logement une couche de gravier de drainage suffisant pour garantir le possible écoulement de l'eau (environ 30cm). FIG.4
- Insérez le tube ondulé T dans le trou approprié du pôle. FIG.4

Post Sales Support

HQ 1-800-388-3382 support@zaneen.com



EN

- Installation and electrification must be carried out by a qualified electrician, only.
- Observe all relevant building codes and regulations.
- Prior to installation or repair: disconnect power; it is the installer's responsibility to ensure for all electrical, mechanical and thermal compatibility.
- The LED light source contained in this fixture shall only be replaced by Zaneen, or a person approved by Zaneen.
- Recommendations: Keep the instruction sheet(s) in the event of maintenance and/or disassembly.

Access detailed spec sheets from www.zaneen.com

FR

- L'installation et l'électrification doivent être effectuées uniquement par un électricien qualifié.
- Respectez tous les codes du bâtiment et réglementations en vigueur.
- Avant l'installation ou la réparation: débranchez l'alimentation électrique; Il incombe à l'installateur de s'assurer de la compatibilité électrique, mécanique et thermique.
- La source de lumière LED contenue dans ce luminaire ne doit être remplacée que par Zaneen, ou une personne approuvée par Zaneen.
- Recommandations: Conservez la (les) fiche (s) d'instructions en cas de maintenance et / ou de démontage

Accéder aux fiches techniques détaillées sur www.zaneen.com

Disclaimer: Applicable only when Zaneen's lighting fixtures are properly installed on correct line voltage, and under normal conditions of use.

Zaneen Warranties are itemized below:

- All products to be free from defect in materials and workmanship: 1 Year (12 months) Limited Warranty from the invoice date (excluding lamps)
- LED engines and Power Supplies: 5 Years Limited Warranty from the invoice date.
- Transformers and Ballast Warranty: 3 years Limited Warranty from the invoice date.
- Purchaser's sole recourse after the warranty period, for defective power supplies, ballasts or other components manufactured by a third party, is against such third-party manufacturer.

Warranty claims regarding the product(s) must be submitted in writing within 30 days, of discovery of the defect.

Zaneen uses only electrical components, which are produced by responsible manufacturers. Components that may fail in service within the warranty period, under normal use, will be replaced at no charge.

Zaneen will not assume labour or transportation charges in connection with replacement of such parts, nor for removal or re-installation of equipment or parts, nor for consequential damages or losses.

The warranty extended to Zaneen by the manufacturers of the electrical components is passed on to our customers.

At its option, Zaneen will repair or replace, any fixture defective as provided herein if such fixture is returned by the purchaser within the warranty period, provided Zaneen has issued a written "Return Goods Authorization". Such repair or replacement is the exclusive remedy against Zaneen and Zaneen is not responsible for damage of any sort whatsoever, including incidental and consequential damages or losses.

This warranty extends only to replacement defective fixtures or components and no allowance will be made for labour or transportation charges in connection with replacement of such parts, nor for removal or re-installation of equipment or parts unless specifically authorized in writing by Zaneen prior to any work being performed.

This warranty only applies when the products are installed in applications in which ambient temperatures are within normal temperatures and are operated within the electrical values shown on the LED driver label.

Zaneen Interior rated luminaries are not protected from environmental conditions, such as salt content from sea air. Therefore, any damages resulting from exposure to salt air, or other harmful environmental conditions, will not be covered under Zaneen Warranty.

Zaneen will not be responsible under warranty for any failure of the product that results directly or indirectly from improper installation and/or external causes such as: acts of nature, physical damage, and exposure to adverse or hazardous chemicals or other substances, use of harsh cleaning agent or harsh chemicals.

Warranty for any substantial deterioration in the product finish caused by failure to clean, inspect or maintain the finish of the product. The end user is responsible for the structural integrity of existing foundations, anchorages, or structures and all consequences arising from their use.

Zaneen will not be responsible under warranty for any failure of the product that results directly or indirectly from improper installation and/or external causes such as: acts of nature, physical damage, and exposure to adverse or hazardous chemicals or other substances, use of harsh cleaning agent or harsh chemicals.

The end user is responsible for the structural integrity of existing foundations, anchorages, or structures and all consequences arising from their use.